

CROWN LINE

RICE COOKER

MODEL: RC-170



220-240V, 50/60Hz, 700W, 2.8L

INSTRUCTION MANUAL

IMPORTANT SAFEGUARDS

1. Read all instructions carefully.
2. Do not touch hot surfaces Use handles.
3. To prevent electrical hazards do not immerse cord, plug and rice cooker (heating plate) in water or other liquid.
4. **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.**
5. Don't move the Rice Cooker when it is working.
6. Unplug appliance from Socket when not in use and before cleaning. Allow appliance to cool completely before putting on or taking off parts.
7. **If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.**
8. Use of accessory attachment not recommended by manufacturer may cause hazards.
9. Do not use this product outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place appliance on or near gas or electric burner, or in heated oven. **The appliance must not be immersed in water.**
12. Extreme caution must be used when moving and appliance containing hot oil or other hot liquids.
13. Only plug cord into wall outlet, not extension cords. To disconnect, remove by plug, not cord.


COOKING HINTS

Washing Rice: Bran gives an unpleasant odours to cooked rice. To remove bran, rice should be washed thoroughly in lukewarm water. However, washing rice may cause loss of vitamins and nutrition.

“Keep Warm” feature: Using this feature for more than 12 hours may cause discoloration or odor. The sooner the rice is served, the better it will taste. "Keep Warm" should be used during meal.


Steaming: Put the water as needed into the cooking pot. Add steam tray on top of the cooking pot or steam rack in the pot. If 2 steam trays are used, the food which needs less time(ex. shrimp, fish) should be put in upper one. If you choose to cook rice and do the steaming at the same time, additional 1/8 cup of water should be added in the cooking pot for each steam tray used.

Stir – frying: This cooker is designed to heat up cooking oil automatically. Add cooking oil in the pot, push down switch to “COOK”. In 3 – 5 minutes, the switch will go up to “WARM”. It means the cooking oil is hot for cooking. Before stir – frying, push switch to “COOK” again.



plug it in until ready to cook. Otherwise, rice may be spoiled. If the pan is not in cooker, cooking will not begin.

5. The Red indicator light tells you that the cooking has started.
6. When the rice is done, the switch will pop up. At the same time “COOK” light will go off and “KEEP WARM” light will go on, indicating the “Keep Warm” function will continue to keep rice warm.
7. After the switch pops up, leave covered for 6–8 minutes to steam rice.
8. Unplug after use. Grasp the plug, not the cord



14. Do not use appliance for other than intended use.

- * These units are “for household use.”
Preheating of the appliance is not necessary.

OPERATING INSTRUCTIONS:

Please read instructions carefully before using the appliance(s).

CAUTIONS TO READ BEFORE USING RICE COOKER:

1. Use this product with correct AC outlet only.
2. Be sure to unplug AC cord when the pan is not inside the cooker, or when the cooker is not being used. Remember 'keep warm' feature operates whenever the AC cord is plugged in.
3. If the switch button is difficult to press to the “COOK” position, do not try to force it down. This difficulty usually occurs when pan is not fully inserted or when cooking has just finished.
4. Always close the lid completely after each serving to keep rice from drying or discoloring.
5. Never leave the rice spoon or other utensil in the pan when using “KEEP WARM” feature.
6. Do not use the keep warm feature to reheat rice that has been previously cooked.
7. The inner pot and surface of the heater plate must remain free of foreign matter to prevent malfunctions.

THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE.

Any time rice cooker is plugged into a Socket and the switch is not set for cooking, the “Keep Warm” feature is operating.

MAINTENANCE PROCEDURES

CLEANING:

After using the rice cooker, unplug the AC cord and let unit cool.

1. Remove inner pot and lid to wash them in hot sudsy water, taking care to rinse completely; then dry with a soft cloth.
2. Clean the outer side of cooker with a clean damp cloth, Never clean any part of cooker with abrasive or harsh cleaners. Instead, use a damp cloth or sponge with water and mild dish detergent. Do not submerge any part of cooker in water except inner pot and lid
3. Grains of rice, or other foreign matter, may become stuck to heating plate. These must be removed to prevent uneven cooking. It may be necessary to use a knife or similar instrument to remove cooked rice. Afterwards, steel wool can be used to smooth out and polish the area to insure good contact between heater and bottom of inner pot.

4. Improper cleaning of cooker may cause unpleasant odours.
5. Any residue of vinegar or salt may cause pan to corrode.

HOW TO USE

1. Measure rice with the given measuring cup. One cup uncooked rice makes approximately 3 cups cooked rice. Wash rice in a separate bowl until water is relatively clear.
2. Place washed rice in the pan. Add water in the cooking pot according to the following standard:

USING THE MEASURING CUP (For all types)

<u>Raw rice by cup</u>	<u>Water added to the line on pot</u>
10 cups	10 – 10 1/2 cups
8 cups	8 – 8 1/2 cups
6 cups	6 – 6 1/2 cups
4 cups	4 – 4 1/2 cups
2 cups	2 – 2 1/2 cups

3. Set pan in cooker. To place correctly, turn pan gently to right and left. Close the cover firmly.
4. Attach the AC cord to the cooker and plug it in. Do not