

### warranty card

Dear Sir/Madam:  
How do you do!  
Thank you for choosing our product, to protect your rights, please keep the warranty card, if there is quality problem, please contact your local dealer.

Name: \_\_\_\_\_ Model: \_\_\_\_\_  
Place of purchase: \_\_\_\_\_  
Phone: \_\_\_\_\_ Date of Purchase: \_\_\_\_\_  
Address: \_\_\_\_\_

### Notice

- 1) From purchase date, all users enjoy one-year maintenance service, please chat directly with the dealers.
- 2) Other accessories, such as consumption of material, is not under warranty.
- 3) When need maintenance, please show this card and purchase receipt or invoice, then is valid.

### warranty

1. Damage caused by careless use or an error.
2. This warranty card is lost or damaged.

### Functions and Features

- Humidification and purification, addition of oxygen
- ※ To improve the indoor temperature, dispel the drying, to increase the humidity. Hearten spirit, improve work efficiency.
  - ※ Negative ions to purify air, eliminate odor of smoke, decomposition, mold and other harmful substances.
  - ※ Release negative charges, activated oxygen molecules that make the body's oxygen intake increasing 20% and more of carbon dioxide discharge 15%

### Cosmetology, Health care

- ※ Moisturizes your skin, ion directly touching your face, and the face stem cell fast activation. The delicate skin smoothing, more health and vitality.
- ※ Negative ions promote metabolism, fresh air, eliminating fatigue, effectively prevention of air-sickness.

### Treatment, Decoration

- ※ Blended with special potion or Radix, white vinegar, stop the flu, pneumonia-like virus infestation, respiratory patients to create a good convalescence space.
- ※ Add air freshener or fragrance oil, etc. make indoor atmosphere cozy and the integration of modern office and home environment of the individual pursuit, rendering for romance.

Abnormal phenomenon	Reason	Processing methods
Indicator isn't light, no wind, No fog	Power switch is not turned on	Plug in the power plug and turn on the power switch
Indicator Light, with wind no fog	Readjust the switch is not open	Re-adjust the switch for amount of fog
There is unusual smell in sprayed fog	new machine, the water in the tank water is not clean	Open the water tank, put it in the shade for 12 hours. Clean water tank. replace a tank of water
Indicator light, no wind, no fog	The water level in the tank is too high	Pour some water in the tank, then tighten the radiator cap
Spray a small amount of fog	The fouling water of transducer is dirty or stored too long	Cleaning transducer, then replace clean water

### Maintenance and cleaning

Before cleaning, be sure to turn off the power, unplug it.  
Cleaning the tank: one time in two to three weeks.  
If it has scale after unscrewing the tank, use a soft cloth dipped in white vinegar or detergent to scrub and rinse with water.  
External cleaning humidifier:  
Use a soft cloth in warm water which is below 40 °C to rinse, wipe the stains in surface, spray nozzle can be rinsed directly with water  
Humidifier Collection:  
When the long-term no need, clean it, then dry it back into the original packaging in a dry place.

### Warning

Please note that never to use a sharp instrument to touch the hard oscillation transducer. only can be cleaned with a soft cloth.  
You can not use stained with chemical solvents, gasoline, kerosene to wipe the surface. Do not use detergent to clean. Best with clean water.  
When cleaning, to avoid the water body, in order to avoid internal electrical parts wet, failure.  
Do not use and disassemble the body element.

### Smart Humidifier

### Instruction

Thank you for purchasing our products, in order to make our products better for you, please read this manual carefully before use, and keep it in order to facilitate your future maintenance and warranty.



### Expert suggestion

When adding the appropriate white vinegar or Radix, can effectively remove the air of harmful bacteria and prevent influenza virus.

### Operation matters needing

1. Must not add more than 40 °C hot water into the tank and sink to avoid discoloration or deformation.
2. Must not let the water flow into the body from the air.
3. When the indoor temperature is below 0 °C, please pour the the water from the sink and the tank, In order to avoid freezing, cause damage to the components.
4. Do not place metal products, chemicals, detergents, etc. into the sink, otherwise, there will be atomized or undesirable phenomena.
5. If the water stay in the tank for a long time, please do not move, otherwise, the water overflows into exile machin, which will have experience failure.
6. Do not place the humidifier in bright light or where direct exposure to hot air.
7. Do not place the humidifier on the air outlet, and try to stay away from furniture and electrical products.
8. Do not add water directly to the body sink.
9. If long-term no need, turn off the power, unplug it.
10. Must do not turn off the power to pour the remaining water in the tank, otherwise it will burn immediately transducer.
11. When filled with water, can be used continuously for 7-12 hours, without adding water.
12. Adding pure water which can be consumed directly, to avoid the growth of bacteria.

### Safety precautions

1. Please don't use wet hand to pull the plug, as this will create an electric shock hazard.
2. When the body tilted, please cut off the power supply, then further processing.
3. When powered, do not touch the transducer, or causes the feeling of pain.
4. Before cut off the power supply, should not be decomposed body to avoid electric shock.
5. Do not allowed to replace the power cord.

### Common fault handling

### Product structure



### Basic Parameters

Model No.	Rated voltage	Rated Power	Capacity	Maximum evaporation	Noise
HF-415	220V-50HZ	25W	3L	380m/H	<30dB(A)

### Easy Operation

Lay aside the organism level in the suitable place. Takes out the water tank, opens the water tank, then reverse the box lid, and pours into clean running water. For tightening for the convenience the lid, as the tank isn't water leakage (do not need to turn on the too tightly). Wipe off Water drop in all around the water tank, and make the water tank installed. Access to the AC power source, knob clockwise to open the switch, according to user's need to adjust the size of the amount of fog, when humidity indicator lighting, the humidification amount is divided stepless adjustment, built-in fantasy lights, inside safety device set automatic protection. When lack of water indicator lighting, if continue to use, turn off the power.

## كينراون

**موديل:**HF-415

**جهاز ترطيب أيوني سلبي**

**إرشادات**

نشكركم على شراء منتجائنا حيث نحرض على تزويدكم بأفضل منتجاتنا وبالتالي نرجو قراءة هذا الدليل بعناية قبل الاستخدام والاحتفاظ به لتسهيل الصيانة والضمان في المستقبل.



جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

جهاز ترطيب أيوني سلبي

**إقتراح خبير**

عند إضافة الخل الأبيض أو الراديكس المناسب، يمكن إزالة البكتيريا الضارة من الهواء بشكل فعال ومنع فيروس الأنفلونزا.

**الامور التي يتعين مراعاتها عند تشغيل الجهاز**

- عدم إضافة أكثر من 40 درجة مئوية من الماء الساخن إلى الخزان والمغسلة لتجنب أي تغيير في اللون أو تشويهات.
- عدم السماح بتدفق الماء إلى الجهاز من الهواء.
- عندما تكون درجة الحرارة الداخلية أقل من صفر درجة مئوية، يرجى صب الماء من الحوض والخزان لتجنب التجميد والتسبب في تلف المكونات.
- عدم وضع المنتجات المعدنية والمواد الكيميائية والمنظفات وما إلى ذلك داخل الحوض وإلا سيؤدي ذلك إلى ظهور رذاذ متناثر أو أوضاع غير مرغوب فيها.
- إذا بقي الماء في الخزان لفترة طويلة، يرجى عدم التحرك، وإلا سيطفح الماء إلى داخل آلة المنفى، مما يؤدي إلى فشل التجربة.
- عدم وضع جهاز الترطيب في الضوء الساطع أو في مكان التعرض المباشر للهواء الساخن.
- لا تضع جهاز الترطيب على مخرج الهواء ومحاولة إبعاده عن الأثاث والمنتجات الكهربائية.
- عدم إضافة الماء مباشرة إلى حوض الجهاز.
- إذا لم تكن هناك حاجة لإستخدام الجهاز على المدى الطويل ، يجب إيقاف وفصل التيار الكهربائي.
- عدم قطع التيار الكهربائي عن صب الماء المتبقي في الخزان وإلا سيحترق محول التيار الكهربائي على الفور.
- عند تعبئة الجهاز بالماء، يمكن استخدامه بشكل متواصل لمدة 7-12 ساعة من دون إضافة الماء.
- إضافة الماء النقي الذي يمكن استهلاكه مباشرة لتجنب نمو البكتيريا.

**التجميل والرعاية الصحية**

- يرطب بشرتك، حيث يلامس الأيون وجهك مباشرة، وتقوم الخلايا الجذعية بالوجه بالتنشيط السريع. وتنعيم البشرة الرقيقة و مزيد من الصحة والحيوية.
- الأيونات السالبة تعزز عملية التمثيل الغذائي والهواء النقي والقضاء على التعب والوقاية بشكل فعال من دوار الهواء.

**العلاج والديكور**

- ممزوج بجرعة خاصة أو راديكس و الخل الأبيض مما يؤدي الى إيقاف الأنفلونزا والالتهاب الرئوي والإصابة بالفيروسات ومرضى الجهاز التنفسي لخلق مساحة جيدة من النقاهاة.
- القيام بإضافة معطر هواء أو زيت العطر، وغيره. وجعل الجو الداخلي مريحًا ما يؤدي إلى تكامل المكاتب الحديثة والبيئة المنزلية لتحقيق جو من الرومانسية على المستوى الفردي.

ظاهرة غير طبيعية	السبب	طرف العلاج
المؤشر ليس مضاء ولا رياح ولا ضباب	عدم تشغيل مفتاح التيار الكهربائي.	توصيل قابس التيار الكهربائي وتشغيل مفتاح التيار الكهربائي.
ضوء المؤشر مع رياح وعدم وجود ضباب	إعادة ضبط المفتاح غير مفتوح.	إعادة ضبط المفتاح لكمية الضباب.
هناك رائحة غير عادية في الضباب المرشوش	الجهاز جديد والماء في الخزان غير نظيف	فتح خزان المياه ووضعه في الظل لمدة 12 ساعة. وتنظيف خزان المياه. استبدال خزان المياه
ضوء المؤشر، لا رياح و لا ضباب	مستوى الماء في الخزان مرتفع جدًا	صب بعض الماء في الخزان، ثم ربط غطاء الرادياتير
رش كمية صغيرة من الضباب	المياه الملوثة لمحول الطاقة متسخة أو مخزنة لفترة طويلة	تنظيف محول الطاقة، ثم استبدال المياه النظيفة

**إحتياطات السلامة**

**معالجة الأخطاء الشائعة**

- عدم استخدام يد مبتلة لسحب القابس، لأن ذلك سيسبب خطر حدوث صدمة كهربائية.
- عندما يميل جسم الجهاز، يرجى قطع التيار الكهربائي، ثم مزيد من المعالجة.
- عند تشغيل الجهاز يجب عدم لمس محول التيار الكهربائي لان ذلك سوف يتسبب في الشعور بالألم.
- قبل قطع التيار الكهربائي، يجب ألا يكون متحللا لتجنب الصدمات الكهربائية.
- عدم السماح باستبدال سلك التيار الكهربائي.

### هيكل الجهاز

مخرج الضباب -مستوى الماء - توقيت الترطيب - مؤشر لون مزدوج - ضبط الضباب

**المقاييس الأساسية**

رقم الموديل	الجهد المقدر	الطاقة المقدرة	السعة	التبخر الاقصى	الضجيج
HF-415	220 فولت - 50 هرتز	25 واط	3 لتر	380 د/س	<30dB(A)

**سهولة التشغيل**

القيام بوضع مستوى الجهاز جانبا في مكان مناسب. وإخراج وفتح خزان المياه ثم قلب غطاء الصندوق، وسكبه في ماء جارٍ نظيف من أجل إحكام الغطاء والراحة، حيث أن الخزان لا يتسرب منه الماء (لا يتطلب الامر تشغيل المخرطة بإحكام شديد). يجب مسح قطرة ماء في جميع أنحاء خزان المياه والقيام بتثبيت خزان المياه. ويمكن الوصول إلى مصدر تيار كهربائي متردد والضغط على المقبض في اتجاه عقارب الساعة لفتح المفتاح، بحسب حاجة المستخدم إلى ضبط حجم كمية الضباب، وعند إضاءة مؤشر الرطوبة، يتم تقسيم كمية الترطيب إلى تعديل غير متدرج، وأضواء خيالية مدمجة، ويتم ضبط جهاز الأمان الداخلي على الحماية التلقائية. وفي حالة عدم وجود إضاءة مؤشر الماء، إذا استمر في الاستخدام، يجب إيقاف تشغيل التيار الكهربائي.

**الصيانة والتنظيف**

قبل التنظيف، التأكد من إيقاف تشغيل التيار الكهربائي وفصله.
تنظيف الخزان: مرة واحدة كل أسبوعين إلى ثلاثة أسابيع.

إذا كان به ترسبات بعد فك الخزان، يجب استخدام قطعة قماش ناعمة مغموسة في الخل الأبيض أو منظف لفركها وشطفها بالماء.

**مرطب التنظيف الخارجي:**

يجب استخدام قطعة قماش ناعمة في ماء دافئ أقل من 40 درجة مئوية للشطف، ومسح البقع الموجودة على السطح، ويمكن شطف فوهة الرش مباشرة بالماء.

**مجموعة المرطب:**

عندما لا تكون هناك حاجة لذلك على المدى الطويل، قم بتنظيفه، ثم جففه مرة أخرى في العبوة الأصلية في مكان جاف.

**تحذير**

يرجى ملاحظة أنه لا يجوز مطلقًا استخدام أداة حادة لملامسة محول التذبذب الصلب. يمكن تنظيفه فقط بقطعة قماش ناعمة.

لا يجوز استخدام الملون بالمذيبات الكيماوية والبنزين والكبروسين لمسح السطح.

عدم استخدام المنظفات للتنظيف. من الأفضل بالماء التنظيف.

عند التنظيف يجب تجنب المسطحات المائية، لتجنب الأجزاء الكهربائية الداخلية الرطبة والأعطال.

عدم استخدام وتفكيك عناصر الجسم.